


# How to set up the nozzle level check jig


## What's included




- 2 T-pieces
- 1 Cross bar

Note: this jig does not come with the 3D Touch as the nozzles are levelled during the build process. This kit is sent out with any replacement hot ends or extruder upgrade kits.


## How to set it up



Place the T-pieces across the x axis bars ensuring the parts are, as pictured, resting on the bars not the belt. Place one either side of the X carriage.



Place the cross bar into the slots on the T-pieces as pictured.



Once your jig is set up as pictured please [click here](#) to go to the instructions on how to level the nozzles. Note: the nozzle levelling jig replaces the bed in these instructions.